

II – 1100-1

INSTALLATION INSTRUCTIONS ACSI MODEL 1104, 1106, 1108, 1100-10 & 1100-12 HINGES

APPLICATION PROCEDURE


- FOR USE WITH 4,6,8,10 &12 WIRE CONCEALED ELECTRIC THROUGH-WIRE HINGES.
- STEEL HINGES FOR INTERIOR USE ONLY.
- BRASS AND STAINLESS STEEL HINGES FOR INTERIOR AND EXTERIOR USE.
- INSTALL 302-03-03 7” MORTAR GUARD ON MORTAR FILLED FRAMES. FAILURE TO INSTALL MORTAR GUARD WILL VOID MANUFACTURER’S WARRANTY.

ELECTRICAL RATINGS

- EACH WIRE RATED 50 VOLTS AC/DC AT 3.5 AMPS (MAX.) CONTINUOUS, OR 16 AMPS (MAX.) PULSE.
- MAXIMUM PULSE WIDTH: 400 msec.
- MINIMUM “OFF” TIME BETWEEN PULSES: 10 SECONDS

WIRE GAUGE SIZE: 28 AWG (TYPICAL FOR ALL MODELS SHOWN).

- USE SCHEMATICS FOR WIRE COLOR CODES.



MODELS: 1104, 1106, 1108, 1100-10 & 1100-12 THROUGH WIRE HINGES

DOOR AND FRAME PREPARATION

- DOOR AND FRAME MUST BE PREPARED IN ACCORDANCE WITH THE APPROPRIATE THROUGH WIRE HINGE TEMPLATE.
- THROUGH WIRE TYPE HINGES ARE NON-LOAD BEARING AND MUST BE MOUNTED IN THE CENTER HINGE POSITION ONLY.
- DO NOT ATTEMPT TO DISASSEMBLE HINGE. HINGE MUST BE INSTALLED ASSEMBLED. IF HINGE IS DISASSEMBLED, MANUFACTURER'S WARRANTY WILL BE VOID.
- WIRE ACCESS HOLES MUST BE FREE OF BURRS AND SHARP CORNERS. CHECK TO MAKE SURE THAT HINGE FITS FREELY IN PREP. TO AVOID DAMAGING AND OR SHORTENED LIFE, DO NOT FORCE HINGE INTO PREP HOLES.
- HANG THE DOOR ON THE TOP AND BOTTOM HINGES FIRST (NOTE: THESE ARE NON-ELECTRICAL HINGES).

INSTALLATION

- ATTACH WIRES IN ACCORDANCE WITH PROJECT WIRING DIAGRAMS.
- OPEN DOOR TO 90° OR MORE FOR ACCESS TO JAMB PREPS.
- EXTRACT INTERIOR WIRING THROUGH THE PREP HOLES FROM THE DOOR AND JAMB.
- TERMINATE WIRE CONNECTIONS WITH APPROPRIATE CRIMP SPLICES OR WIRE NUTS.

NOTE: IT IS HELPFUL TO STAGGER TERMINATIONS. THIS ALLOWS FOR EASY INSERTION OF WIRES THROUGH PREP HOLES.

- **DO NOT HANG HINGE BY WIRES DURING INSTALLATION OR SERIOUS DAMAGE COULD OCCUR.**
- INSULATE ALL ENDS OF UNUSED WIRES.
- AFTER ALL TERMINATIONS ARE COMPLETED, CAREFULLY SLIDE WIRES THROUGH PREP HOLE MAKING SURE THAT WIRES ARE PLACED SO THEY WILL NOT BE CUT OR PINCHED AS HINGE IS INSTALLED.

WIRE GAUGE SIZE: 28 AWG (TYPICAL FOR ALL MODELS SHOWN).

- FOR CURRENT RATINGS LARGER THAN 1 AMP, USE TWO OR MORE WIRES IN PARALLEL. MAKE SURE SAME COLORED WIRES ARE CONNECTED PROPERLY ON BOTH SIDES OF HINGE.
- MAXIMUM TOTAL CURRENT FOR A FOUR WIRE HINGE IS TWO TIMES THE MAXIMUM CURRENT SHOWN IN THE ELECTRICAL RATINGS CHART: TWO WIRES CURRENT IN, TWO WIRES CURRENT OUT OF DOOR.
- MAXIMUM TOTAL CURRENT FOR AN EIGHT WIRE HINGE IS FOUR TIMES THE MAXIMUM CURRENT SHOWN IN THE ELECTRICAL RATINGS CHART: FOUR WIRES CURRENT IN, FOUR WIRES CURRENT OUT OF DOOR.

