

SERIES 1320 PUSHBUTTON SWITCH WITH TIME DELAY

COVERS THE FOLLOWING MODELS:

- 1320-4 PUSH-BUTTON SWITCH WITH TIME DELAY AND 1 STATUS INDICATOR (RED).

MOUNTS IN A DOUBLE GANG WALL MOUNT ELECTRICAL BOX.
SIZE 4" SQ. X 2-1/8" DEEP. (RACO #680 OR EQUIVALENT)



ELECTRICAL SPECIFICATIONS

- 24VAC/VDC +/- 10% INPUT
- CONTACTS RATED AT 1A @ 30VDC
- CURRENT DRAW @ 24VDC: 5mA (STANDBY); 40mA (ACTIVATED)

RED LED STATUS INDICATOR

RED LED TURNS ON WHEN RELAY IS ENERGIZED FOR
A DELAYED AMOUNT OF TIME AFTER PUSHBUTTON IS DEPRESSED.

ADJUSTING THE TIME DELAY CIRCUIT

- TO INCREASE DELAY TIME, TURN POTENTIOMETER COUNTERCLOCKWISE.
- TO DECREASE DELAY TIME, TURN POTENTIOMETER CLOCKWISE.
- DELAY RANGE: 0 - 40 SECONDS

MOUNTING INSTRUCTIONS

DO NOT USE GANGABLE SWITCH BOXES WHERE THE FACE PLATE MOUNTING
HOLE TABS FACE OUTWARD FROM THE BOX. THERE WILL NOT BE ENOUGH
HEIGHT CLEARANCE FOR THE P.C. BOARD.

