# EXIT DEVICE INSTALLATION INSTRUCTIONS AUTHORIZED EGRESS SWITCH (AE) AND LATCH MONITORING SWITCH (LM)

FOR USE WITH ALL ACSI MONITORED EXIT DEVICE MODIFICATIONS
AUTHORIZED EGRESS (AE) SWITCH MONITORS EGRESS BY PUSHBAR ACTIVATION OF EXIT DEVICE
LATCH MONITORING (LM) SWITCH MONITORS THE LATCH MECHANISM OF EXIT DEVICE

## **AUTHORIZED EGRESS (AE)**

#### **ELECTRICAL SPECIFICATIONS**

- SPDT MONITOR SWITCH
- CONTACT RATING: 3 AMP @ 125VAC 2 AMP @ 30VDC

#### **COLOR CODE FOR WIRES**

- YELLOW WIRE: COMMON
- RED WIRE: NORMALLY OPEN
- GRAY WIRE: NORMALLY CLOSED

## LATCH MONITORING (LM)

#### **ELECTRICAL SPECIFICATIONS**

- SPDT MONITOR SWITCH
- CONTACT RATING: 3 AMP @ 125VAC 2 AMP @ 30VDC

### **COLOR CODE FOR WIRES**

- BLACK WIRE: COMMON
- WHITE WIRE: NORMALLY OPEN
- RED WIRE: NORMALLY CLOSED

