

ELECTRIC LOCK M1510/1520C

HAGER 3800 SERIES, I-TEK M9000 SERIES AND OAK SECURITY GROUP M9000 SERIES LOCKS

FUNCTION CHANGE INSTRUCTIONS

TO CHANGE THE LOCKING FUNCTION FOLLOW THE
BELOW INSTRUCTIONS CAREFULLY.

STEP 1: REMOVE THE 4 COVER SCREWS AND COVER

STEP 2: USING THE ILLUSTRATION BELOW, REMOVE PIN AND REPLACE PIN
IN PROPER HOLE AS FOLLOWS

A FOR FAIL SECURE M1520C (POWER UNLOCK) FUNCTION

B FOR FAIL SAFE M1510C (POWER LOCK) FUNCTION

STEP 3: REPLACE COVER AND SCREWS. MAKE SURE SOLENOID IS PROPERLY
POSITIONED IN COVER SLOT.

