EXIT DEVICE INSTALLATION INSTRUCTIONS

K-125 SWITCH KIT

DORMA 9000 SERIES EXIT DEVICES
SWITCH MONITORS EGRESS BY PUSHBAR ACTIVATION OF EXIT DEVICE

INSTALLATION INSTRUCTIONS

STEP 1: REMOVE DEVICE FROM DOOR IF APPLICABLE.

STEP 2: SLIDE END COVER OFF OF DEVICE.

STEP 3: REMOVE 2 SCREWS THAT HOLD HEAD ASSEMBLY TO CHANNEL AND REMOVE HEAD.

STEP 4: REMOVE SIX SCREWS FROM BACK OF DEVICE AND SLIDE PUSH-BAR ASSEMBLY OUT OF CHANNEL.

STEP 5: REMOVE E-CLIP FROM REAR PIVOT ASSEMBLY ON SIDE THAT IS SHOWN IN ILLUSTRATION.

STEP 6: INSTALL SWITCH KIT K-125 ONTO PIVOT PIN AND REASSEMBLE E-CLIP.

(NOTE: MAKE SURE THAT SWITCH ARM IS LOCATED UNDER PIVOT ARM AS SHOWN IN ILLUSTRATION).

STEP 7: CHECK FOR PROPER SWITCH ACTIVATION WHEN PUSHBAR IS FULLY DEPRESSED, REFER TO COLOR CODE CHART FOR PROPER WIRING PER APPLICATION.

STEP 8: MAKE SURE COLOR CODE FOR WIRES CHART IS USED FOR PROPER HOOK-UP OF SWITCH CONTACTS.

STEP 9: RE-ASSEMBLE EXIT DECIVE. (REVERSE STEPS 1 THROUGH 4)

